




# SIZE 34 EP BEARING LIFE VS. SHAFT LOAD



**SPEED (RPM)** refers to the gearheads output shaft speed.

**LIFE (HRS)** = (# of lifetime revolutions) ÷ (60 x rpm)

**F<sub>RADIAL</sub>** is calculated at 1/2 the shaft length.

